Installing Your Printer to the Network for the First Time

PIXMA iP110

Windows OS

Installing Your Printer to the Network for the First Time

PIXMA iP110
Windows OS

Preparing to Connect the Printer to the Network **3**
Network Requirements 3
Notes on Wireless Connection 4
Installing the Drivers & Software **5**

Preparing to Connect the Printer To the Network

Network Requirements

Before connecting the machine to the network, make sure that configuration of the computer and access point or router is complete, and that the computer is connected to the network.



Wireless Connection

Before connecting the machine to the network, the computer needs to be connected to the network. Make sure that configuration of the computer and access point or router is complete.

Preparing to Connect the Printer To the Network



Notes on Network Connection

• The configuration, router functions, setup procedures and security settings of the network device vary depending on your system environment. For details, refer to your device's instruction manual or contact its manufacturer.

• In an office setup, consult your network administrator

• If you connect to a network that is not protected with security measures, there is a risk of disclosing data such as your personal information to a third party.

• Place the machine and computer on the same network segment.

Installing the Drivers & Software

Software Installation

To use the machine by connecting it to a computer, software including the drivers needs to be copied (installed) to the computer's hard disk. Installation time varies depending on the computer environment or the number of application software to be installed.

IMPORTANT

• Log on as the administrator (or a member of the Administrators group).

• Quit all running applications before installation.

• Do not switch users during the installation process.

• Internet connection may be required during the installation. Connection fees may apply. Consult the internet service provider.

• It may be necessary to restart your computer during the installation process. Follow the on-screen instructions and do not remove the Setup CD-ROM during restarting. The installation resumes once your computer has restarted.

• If the firewall function of your security software is turned on, a warning message may appear that Canon software is attempting to access the network. If such a warning message appears, set the security software to always allow access.

Installing the Drivers & Software

To set up the PIXMA iP110 to your wireless network, you must first install the software to your computer. To begin

the setup procedure, insert the Setup CD-ROM into your computer.*

The setup program will start automatically. The setup instructions presented in this document describe the "**Cableless Setup**" method which does not require the need to know the SSID (network name), or network passphrase and does not require the printer to be temporarily connected to the computer with a USB cable.

The **Cableless Setup** is not supported in Windows XP. For Windows XP Users: Use the " **Wireless Setup Using the USB Cable**" method , whereby a USB cable is temporarily connected between the printer and computer during setup.

*If you don't have or cannot use the Setup CD-ROM, follow the steps below to start the setup.

- Download the software (click the link to download)
- Double-click the downloaded .exe file

If the **User Account Control** dialog box appears during the setup, click **Yes** or **Continue**.

Installing the Drivers & Software

Click **Next** on the initial screen.


Canon PIXMA iP110 series
Canon
PIXMA iP110 series
You can select whether to use this printer via USB connection or LAN connection. Follow the on-screen instructions to select the connection method.
Network setup is required when using the printer via LAN connection. If the setup is already completed, the connection is confirmed automatically. If the setup is not completed, follow the on-screen instructions to set up the printer.
Language
Exit
Next

Connecting to the Network

On the following screen, select **Wireless LAN Connection,** then click **Next**.



Connecting to the Network

On the following screen, select **Access Point Connection,** then click **Next**.


Canon PIXMA iP110 series
Select the wireless LAN connection method.
Access Point Connection (recommended)
Connect the computer and the printer via wireless LAN router.
Direct Connection
Directly connect the computer and the printer.
To switch between Access Point Connection and Direct Connection or for more details on the connection method, click [Instructions].
Instructions
Back
Next

Connecting to the Network

Continue following on-screen instructions. On the **Printers on Network List** screen, check the **Setting printer could not be found on the list** checkbox and click **Next**.


Canon PIXMA iP110 series
Printers on Network List
Serial Number
MAC Address
IP Address
Setting printer could not be found on the list
Update
1. To set a printer on the network, select one from the above printers list, and then click [Next].
Serial number can be found on the back of the printer or the Letter of Guarantee.
2. If the setting printer could not be found on the above list, turn on the printer and click [Update].
3. If the printer could not still be found, select [Setting printer could not be found on the list], and the click [Next].
Back
Next

Connecting to the Network

Continue to follow on-screen instructions until you get to Step 2-1, **Setup Procedure Selection**.

Select **Cableless setup** on the **Setup Procedure Selection** screen (2-1).


2-1 Setup Procedure Selection
Select the most suitable connection method from the following.
Connect to WPS-compatible Access Point
WPS
Setting the Access Point Information to the Printer Directly from Computer, without Operating the Access Point
Cableless setup
Cableless setup may take some time. Internet connection may become temporarily unavailable during setup.
Cableless setup is not available on Windows XP. Perform setup with another connection method.
Connect Using Other Methods
Other setup

If the Install .NET Framework screen appears, Click Yes

Connecting to the Network

Carefully follow the instructions on the **Connection via Cableless setup** screen. (3-1).
Click **Next.**


3-1 Connection via **Cableless setup**
B
A
1. Hold down the **Wi-Fi** button (A) on the printer until the **POWER** lamp (B) flashes 2 times, then release the **Wi-Fi** button after the second flash.
Start Again
Back
Next

Connecting to the Network

Carefully follow the instructions on the **Connection via Cableless setup** screen. (3-2). Click **Next**


3-2 Connection via **Cableless setup**
A
1. Make sure that the Wi-Fi lamp (A) flashes quickly and the **POWER** lamp is lit as shown in the illustration above.
2. Click **Next**, then follow the instructions on the next screen to proceed with setup.
Start Again
Back
Next

Connecting to the Network

Click **Next** on the **Connection completed** screen.



Installing the Drivers & Software

Continue following on-screen instructions. On the **Software Installation List**, select *software to install and click **Next**.

***IIJ Printer Driver** is required and cannot be deselected. We recommend installing **My Image Garden** and **Quick Menu** to take full advantage of the printer's features.


Canon PIXMA iP110 series
Software Installation List
The selected software will be installed. Make sure that the software you want to install is selected, and then click [Next].
IJ Printer Driver 145 MB
User's Manual 10 MB
My Printer 14 MB
My Image Garden 705 MB
Quick Menu 40 MB
Easy-WebPrint EX 110 MB
XPS Driver 130 MB
Drive C: 67390 MB free space
Total used space: 1989 MB
Select All
Clear All
Estimated installation time: 10 to 15 minutes
Installation may take some time depending on your network environment.
Back
Next

Installing the Drivers & Software

Continue following on-screen instructions.

When the **Setup Completion** dialog box appears, click **Complete**.



At this point, setup of the printer and network is complete. Continue to follow any remaining on-screen instructions to finish and exit the setup program.